

# Quick Start Guide

## ESERV-M12T Modbus



1


### Check for All Required Hardware

- ESERV-M12T module
- This Quick Start Guide
- CD with Modbus Gateway Manager s/w and manuals
- Network Cable(s) (not included)
- Serial Cable(s) (not included)
- Power Supply (not included)

2


### Install the Hardware

- Connect a 10 to 58 VDC power supply (Sold separately). 4W for ESERV-M12T



- One Conductor Per Terminal
- Use Copper Wire Only
- Wire Size: 28 to 16AWG
- Tightening Torque: 5 KG-CM
- Wire Temperature Rating: 105°C Minimum (Sized for 60°C ampacity)
- 80°C Maximum Surrounding Air Ambient

- Connect the top RJ45 connector to a network drop using a standard network cable (lower RJ45 is pass-through Ethernet on the model shown below).
- Connect the serial device(s):
  - o RS-232 with DB9: straight-through for DCE device, null modem for DTE device.
  - o RS-232/422/485 with terminal blocks: see Appendix D for pin outs.



3

### LED Status

LED	STATUS
Ready	Blinks if system is operating correctly, once per second normally or three times per second for configuration mode or when reset to factory defaults.
Port 1/ Port 2	On indicates serial port open, blinks when data present
E1	On indicates Ethernet has a link, blinks with data traffic

4

### Mode Switch

Hold in Mode switch for...	Result
0 to 2 seconds	Initiates a Hardware Reset
2 to 10 seconds	Enters Console Mode
Over 10 seconds	Reset to Factory Defaults

5

### Install Modbus Gateway Software

- Insert the included CD and it should auto start.
  - Follow the prompts to install the Modbus Gateway software.
- Note: Be sure you have administrative rights & disable firewalls in Windows XP

6

### Setup the Modbus Gateway Software


- Open the Modbus Gateway Software: click Start→Programs→N-TRON → Modbus Gateway Manager→Configuration Manager.
- The Device Discovery page opens.



- NOTE:** If the device does not connect, cycle (unplug-replug) the power, then try again to connect.
- To configure via the network, select Network.
- If you know the IP address, select "The device is at this address," and type in the IP address.
- If not, select I don't know the IP address of the device.
- Click Connect.

### OR...Setup the Web Interface


- Open a browser and type the IP address of the Modbus Gateway in the Address Bar.
- When the Modbus Gateway is found, the Login window appears.



7

### Login

- Click Login. Password is blank from factory, no password is necessary to operate the ESERV-M12T.
- The Configuration/General page appears.



8

## Setup Network

- I want DHCP** is preselected to set up the network using dynamic IP addressing. The Modbus Gateway is set up at the factory to receive an IP assignment from a DHCP Server. If a DHCP Server is not available on your network, it will default to **169.254.102.39**.
- If a DHCP server is not available and the default address does not work on your PC, change your PC network settings to IP Address: 169.254.102.1, Subnet Mask: 255.255.0.0, Default Gateway: 169.254.102.100. If you are not able to use these settings in your installation, refer to the user's manual for directions to change the Modbus Gateway's TCP/IP settings.

9

## Setup Modbus TCP

### Modbus TCP Settings:

- Connect to Port** identifies TCP port used in TCP client mode. Valid range is 1 to 65535.
- Response timeout** is the maximum response time. Valid range is from 1 to 65535.

### TCP Server Settings:

- Listen on port** identifies TCP port in TCP server mode. Valid range is from 1 to 65535.
- Limit the number of connections**...Controls the number of simultaneous TCP clients that can be connected.
- "...**allow everyone**," "...**allow specific IP address**" & "**allow a range of IP addresses**" are *Connection Filter Mode* options, controlling which TCP clients can connect.

10

## Setup Port 1 Serial

- Change the **Description** of the serial port if needed.
- Set the **Mode** to RS-232, RS 422 (4 wire), RS 485 (2 wire) or RS 485 (4 wire).
- Set the **Baud Rate** to control the speed of the port. Valid speeds range between 75 and 230,400 bits per second.
- Set **Data Bits** to control the number of bits in each character. Only 8 bits is valid when the protocol of the device connected to the port is RTU.
- Stop Bits** controls the number of bits for end of character.
- Parity** controls the error checking mode, with options of No Parity, Odd, Even, Mark and Space.

11

## Setup Port 1 Modbus

- Select the **Attached as Master or Slave**.
- Select the **Modbus** protocol to be used, either **RTU** or **ASCII**.
- As needed, check option boxes for "**Enable Modbus broadcast**," "**Enable OBh Exception**" and "**Enable serial message buffering**."
- Select from 0 to 5 **Modbus Serial Retries**.
- Enter **Milliseconds Modbus Message Timeout**, from 1 to 65535.
- Enter **Milliseconds TX Delay**, from 1 to 65535.
- Set up "Port 2 Modbus" the same, only if it has a Port 2.

12

## Setup Port 1 ID Remap

- Only use this screen if **Modbus Slave IDs** are to be remapped.
- On each line select a range of serial ports to remap. In the 1<sup>st</sup> box enter the first serial port of the range to remap **From**. Valid port IDs range from 1 to 255.
- 2<sup>nd</sup> box - enter the last serial port of the range to remap.
- 3<sup>rd</sup> box - enter starting ID of the range to remap **To**.
- The 4<sup>th</sup> box auto fills based on ranges entered in the first three columns.
- Set up "Port 2 Remap" the same, only if it has a Port 2.

13

## Setup Modbus ID Routing

- Only use this screen if **Modbus Slave IDs** are to be re-routed.
- On each line select the range of IDs to re-route. In the 1<sup>st</sup> box enter the starting ID. Valid IDs range from 1 to 255.
- 2<sup>nd</sup> box - enter the last ID of the range to re-route.
- 3<sup>rd</sup> box - enter the **IP Address** or **Port** that has slave devices attached.
- The 4<sup>th</sup> box shows the IP address of the slave device, if an IP address is chosen in the third box.

14

## Setup Modbus Priority

- Only use this screen if **Modbus Priority** is to be set.
- Enter up to five different priorities, based on **Originating IP Address**, **Modbus ID**, **Modbus Function Code**, or a combination of these.
- IP Address** sets a static IP address for the Modbus gateway.
- Modbus ID** has a valid range from 1 to 255.
- Function Code** has a valid range from 1 to 99.

15

## Save and Logout

- If you have completed the configuration, click Save to save the configuration to the serial server.
- To Logout, click the Logout button.

16

## To Test and Verify Operation

- The primary check for correct operation is the device LEDs. See Section 3 this document for more information.
- For advanced information, see the **Modbus Configuration Manager** menu, at the top of Modbus Gateway Manager screen.
- Select **Diagnostic** for a check of communications status with attached ESERV-M12T device, and then select the device for which the communications check is desired.
- A report of reply times and ping statistics is generated and can be saved.
- Select **Monitor** to review activity logs of attached ESERV-M12T devices, then select the device for which logged information is needed
- Logged information includes **Time**, **Source & Destination**, **Type of event**, **Subscriber ID**, **Data** collected, and **Information** the Modbus Gateway Manager program has gathered since current login of the affected device.